

Таблица совместимости с бытовыми кондиционерами Midea

Бренд	Категория	Тип	Завод	Класс	Серия	Внутренний блок
MIDEA	Split	Wall	MIDEA	inv	Ultimate Comfort MSMT (MT)	MSMTBU-09HRFN1
MIDEA	Split	Wall	MIDEA	inv		MSMTBU-12HRFN1
MIDEA	Split	Wall	MIDEA	inv		MSMTD-18HRFN1
MIDEA	Split	Wall	MIDEA	inv		MSMTD-24HRFN1
MIDEA	Split	Wall	MIDEA	inv	Mission MSMB (MB)	MSMBBU-12HRFN1(BW)
MIDEA	Split	Wall	MIDEA	inv		MSMBCU-18HRFN1(BW)
MIDEA	Split	Wall	MIDEA	on/off	Mission MSMB (MB)	MSMBAU-09HRN1(W)
MIDEA	Split	Wall	MIDEA	on/off		MSMBB-12HRN1(W)
MIDEA	Split	Wall	MIDEA	inv	Blanc MA1 ERP	MSMAAU-07HRDN1
MIDEA	Split	Wall	MIDEA	inv		MSMAAU-09HRDN1
MIDEA	Split	Wall	MIDEA	inv		MSMABU-12HRDN1
MIDEA	Split	Wall	MIDEA	inv		MSMACU-18HRFN1
MIDEA	Split	Wall	MIDEA	inv		MSMADU-24HRFN1
MIDEA	Split	Wall	MIDEA	on/off	Blanc MA1	MSMA1A-07HRN1
MIDEA	Split	Wall	MIDEA	on/off		MSMA1A-09HRN1
MIDEA	Split	Wall	MIDEA	on/off		MSMA1B-12HRN1
MIDEA	Split	Wall	MIDEA	on/off		MSMA1C-17HRN1
MIDEA	Split	Wall	MIDEA	on/off		MSMA1D-24HRN1
MIDEA	Split	Wall	MIDEA	inv	BreezeLess	MSFA-09N8D6-I
MIDEA	Split	Wall	MIDEA	inv		MSFA-12N8D6-I
MIDEA	Split	Wall	MIDEA	inv	BreezeLess	MSFA1-09N8D6-I
MIDEA	Split	Wall	MIDEA	inv		MSFA1-12N8D6-I
MIDEA	Multi	Wall	MIDEA	inv	BreezeLess	MSFA2-09N8D6-I
MIDEA	Multi	Wall	MIDEA	inv		MSFA2-12N8D6-I
MIDEA	Split	Wall	MIDEA	inv	Paramount Inv	MSAG1-07N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG1-09N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG1-12N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG1-18N8D0-I
MIDEA	Split	Wall	MIDEA	inv		MSAG1-24N8D0-I
MIDEA	Split	Wall	MIDEA	on/off	Paramount	MSAG1-07HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG1-09HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG1-12HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG1-07HRN1U-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG1-09HRN1U-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG1-12HRN1U-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG1-18HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG1-24HRN1-I
MIDEA	Split	Wall	MIDEA	inv	Unlimited Inv	MSAG2-07N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG2-09N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG2-12N8C2-I

MIDEA	Split	Wall	MIDEA	inv		MSAG2-18N8D0-I
MIDEA	Split	Wall	MIDEA	inv		MSAG2-24N8D0-I
MIDEA	Split	Wall	MIDEA	on/off	Unlimited	MSAG2-07HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG2-09HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG2-12HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG2-07HRN1U-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG2-09HRN1U-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG2-12HRN1U-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG2-18HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG2-24HRN1-I
MIDEA	Split	Wall	MIDEA	inv	Primary Inv	MSAG3-07N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG3-09N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG3-12N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG3-18N8D0-I
MIDEA	Split	Wall	MIDEA	inv		MSAG3-24N8D0-I
MIDEA	Split	Wall	MIDEA	on/off	Primary	MSAG3-07HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG3-09HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG3-12HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG3-18HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG3-24HRN1-I
MIDEA	Split	Wall	MIDEA	inv	Persona Inv	MSAG4-07N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG4-09N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG4-12N8C2-I
MIDEA	Split	Wall	MIDEA	inv		MSAG4-18N8D0-I
MIDEA	Split	Wall	MIDEA	inv		MSAG4-24N8D0-I
MIDEA	Split	Wall	MIDEA	on/off	Persona	MSAG4-07HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG4-09HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG4-12HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG4-18HRN1-I
MIDEA	Split	Wall	MIDEA	on/off		MSAG4-24HRN1-I
MIDEA	Split	Wall	MIDEA	inv	GAIA	MSCA1BU-09HRFN8
MIDEA	Split	Wall	MIDEA	inv		MSCA1BU-12HRFN8
MIDEA	Multi	Wall	MIDEA	inv	MMAG2	MMAG2-09N8D0
MIDEA	Multi	Wall	MIDEA	inv		MMAG2-12N8D0
MIDEA	Multi	Wall	MIDEA	inv		MMAG2-18N8D0
MIDEA	Multi	Wall	MIDEA	inv		MMAG2-24N8D0
MIDEA	Multi	Wall	MIDEA	inv	MSFA1	MSFA1-09N8D6-I
MIDEA	Multi	Wall	MIDEA	inv		MSFA1-12N8D6-I
MIDEA	Multi	Wall	MIDEA	inv	MSFA2	MSFA2-09N8D6-I
MIDEA	Multi	Wall	MIDEA	inv		MSFA2-12N8D6-I
AXIOMA	Split	Wall	MIDEA	inv	ASX_AZ	ASX07AZ1
AXIOMA	Split	Wall	MIDEA	inv		ASX09AZ1
AXIOMA	Split	Wall	MIDEA	on/off	ASX_A	ASX07A1

AXIOMA	Split	Wall	MIDEA	on/off		ASX09A1
AXIOMA	Split	Wall	MIDEA	on/off		ASX12A1
AXIOMA	Split	Wall	MIDEA	on/off		ASX18A1
AXIOMA	Split	Wall	MIDEA	on/off		ASX24A1
AXIOMA	Split	Wall	MIDEA	on/off		ASX27A1
AURUM	Split	Wall	MIDEA	on/off	ARC_WNMF1	ARC07-WNMF1/I
AURUM	Split	Wall	MIDEA	on/off		ARC09-WNMF1/I
AURUM	Split	Wall	MIDEA	on/off		ARC12-WNMF1/I
AURUM	Split	Wall	MIDEA	on/off		ARC18-WNMF1/I
AURUM	Split	Wall	MIDEA	on/off		ARC24-WNMF1/I
AURUM	Split	Wall	MIDEA	inv	ARC_WDMF1	ARC07-WDMF1/I
AURUM	Split	Wall	MIDEA	inv		ARC09-WDMF1/I
AURUM	Split	Wall	MIDEA	inv		ARC12-WDMF1/I
AURUM	Split	Wall	MIDEA	inv		ARC18-WDMF1/I
AURUM	Split	Wall	MIDEA	inv		ARC24-WDMF1/I
PRIMERA	Split	Wall	MIDEA	on/off	PRAW_MFNA	PRAW-07MFNA/I
PRIMERA	Split	Wall	MIDEA	on/off		PRAW-09MFNA/I
PRIMERA	Split	Wall	MIDEA	on/off		PRAW-12MFNA/I
PRIMERA	Split	Wall	MIDEA	on/off		PRAW-18MFNA/I
PRIMERA	Split	Wall	MIDEA	on/off		PRAW-24MFNA/I
PRIMERA	Split	Wall	MIDEA	inv	PRAW_MFDA	PRAW-07MFDA/I
PRIMERA	Split	Wall	MIDEA	inv		PRAW-09MFDA/I
PRIMERA	Split	Wall	MIDEA	inv		PRAW-12MFDA/I
PRIMERA	Split	Wall	MIDEA	inv		PRAW-18MFDA/I
PRIMERA	Split	Wall	MIDEA	inv		PRAW-24MFDA/I